

Play with the Pit Lane and enjoy racing strategy

Your N-Digital NINCO circuit will reach a new dimension if you add the 'Pit Lane' extension kit. You will control your car's fuel level, decide when to stop for refuelling, think about the better strategy in order to avoid losing time and be the fastest over the track.


Pit Lane (ref. 40203)




Contents
Length: 1,2 m

- (Units): Description
- (6) safety walls
 - (1) Straight 40 cm
 - (2) Individual straight 40 cm
 - (1) Individual refuelling straight 40 cm
 - (1) Exit to pit lane
 - (1) Exit back to the track

Take note!



When mounting it, respect the way of the race of the N-Digital System. The cars get to the pit lane always detouring to the right.



Better if you place the access to the Pit Lane close to a curve, you will avoid that the excess of speed when entering in the fuelling area leaves the car disturbed when it stops.



Always! First connect the Pit Lane to the console and then the transformer. You can place more than one Pit Lane.



Select the mode PS. Introduce the time of the race. Place the ideal number of stops to refuel. Go on! Plan your racing strategy.



Press the button at the controller to get to the Pit Lane and if you don't want to wait for the whole refuelling just press it again and go back to the race!