

### CV #29 Table

| Analog  | Speed steps | Direction | When address is 1-127 | When address is 128-9999 |
|---------|-------------|-----------|-----------------------|--------------------------|
| disable | 28          | normal    | CV29=2 (default)      | CV29=34 (default)        |
| disable | 28          | reverse   | CV29=3                | CV29=35                  |
| disable | 14          | normal    | CV29=0                | CV29=32                  |
| disable | 14          | reverse   | CV29=1                | CV29=33                  |
| enable  | 28          | normal    | CV29=6                | CV29=38                  |
| enable  | 28          | reverse   | CV29=7                | CV29=39                  |
| enable  | 14          | normal    | CV29=4                | CV29=36                  |
| enable  | 14          | reverse   | CV29=5                | CV29=37                  |